



01C



301



270



040



995



3663



494



493



006



038



1065



1015



492



495



013



017




1009



1003



490




02C



005



096



689



3540



2938



834



024



131



2772



031